



QUICK-START INSTRUCTIONS

The following steps will help you to quickly setup a Chem-Trak system. Please refer to the Chem-Trak Installation and Programming manuals for complete details on system setup and operation.

- (1) Confirm Main Power, water inlet and Air Line to Host.
- (2) Power on Host.
- (3) Access Host with default main access code "000".
- (4) Clear error reports on Host.
- (5) Assign Host ID.
- (6) Assign Access Code on Host.
- (7) Set Date and Time if necessary.
- (8) If using more than one host enter "Memory Functions" then "SET EXT MEM ID" and "Clear Memory Module".
- (9) Clear memory on LFP.
- (10) Assign Dispenser ID on LFP.
- (11) Set Access Codes on LFP.
- (12) Set Date and times on LFP.
- (13) Connect Network Cable to Host and KCI module.
- (14) Connect PC cable from PC/Laptop to KCI module.
- (15) Double Click on Winreporter Software Icon on Desktop.
- (16) Click on File Commands Icon Enter Access Code (Default is 000).
- (17) Assign Account Location Setup.
- (18) Logon to Dispenser #X, using your dispenser ID# and Main Access Code.
- (19) Once Logged on to Dispenser click and drag the desired .HEX file in the SETUP FILE Window.
- (20) Once the Setup is transferred into the Host the calibrate each at the host.
- (21) Update the slaves via the Host.
- (22) Run a few loads and make corrections if needed.
- (23) Print Setup/Cycle/Summary reports.



CAUTION: Wear protective clothing and eyewear when dispensing chemicals or other materials. Observe safety handling instructions (MSDS) of chemical mfrs.



CAUTION: To avoid severe or fatal shock, always disconnect main power when servicing the unit.



CAUTION: When installing any equipment, ensure that all national and local safety, electrical, and plumbing codes are met.

DISCLAIMER

Knight LLC does not accept responsibility for the mishandling, misuse, or non-performance of the described items when used for purposes other than those specified in the instructions. For hazardous materials information consult label, MSDS, or Knight LLC. Knight products are not for use in potentially explosive environments. Any use of our equipment in such an environment is at the risk of the user, Knight does not accept any liability in such circumstances.

WARRANTY

All Knight controls and pump systems are warranted against defects in material and workmanship for a period of ONE year. All electronic control boards have a TWO year warranty. Warranty applies only to the replacement or repair of such parts when returned to factory with a Knight Return Authorization (KRA) number, freight prepaid, and found to be defective upon factory authorized inspection. Bearings and pump seals or rubber and synthetic rubber parts such as "O" rings, diaphragms, squeeze tubing, and gaskets are considered expendable and are not covered under warranty. Warranty does not cover liability resulting from performance of this equipment nor the labor to replace this equipment. Product abuse or misuse voids warranty.

KNIGHT LLC, A Unit of IDEX Corporation

World Headquarters
20531 Crescent Bay Drive
Lake Forest, CA 92630
Tel: 949.595.4800
Fax: 949.595.4801
www.knightequip.com

USA Toll Free
Tel: 800.854.3764
Fax: 800.752.9518

Canada
Tel: 905.542.2333
Fax: 905.542.1536

Australia
Tel: 61.2.9725.2588
Fax: 61.2.9725.2025

UK
Tel: 44.1293.615.570
Fax: 44.1293.615.585

North Europe
Tel: 31.53.428.5800
Fax: 31.53.428.5809

South Europe
Tel: 34.93.487.1015
Fax: 34.93.215.2019

North Asia Pacific
Tel: 82.2.3481.6683
Fax: 82.2.3482.5742

Southeast Asia
Tel: 65.9170.0984
Fax: 65.6489.6723